


# IMPORTANT NOTICE


For system to run properly, the anti-frost switch wires must be attached to the control box as shown in the pictures below. The anti-frost switch wires are located on the refrigerant coils at the connection side of the coil.

**For A00175-G01, A00175-G02, and A00175-G03 control box:**  
Connect the Anti-Frost control wires to terminals 3 and 6.



\*Picture above is A00175-G02

**For A00175-G04 Advanced Control Board:**  
Connect the Anti-Frost control wires to terminals labeled “AFS”.



\*Picture above is A00175-G04